Care and Cleaning

- □ Before using, clean the gazebo completely with a soft dry towel.
- □ Do not put your gazebo in wet conditions where there is a risk of rust developing.
- □ When not in use, store in a cool, dry area.

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.